

PR-100




PR-100

The PR-100 interface controller has a pressure sender input and a 10 - 180 ohms or 33 - 230 ohms output.

This interface enables the use of either 2 or 5 point pressure sender input with a resistive output enabling you to connect to either a analogue gauge or an engine management system that requires a resistive sender input.

Example 1



Example 2

